

**SECTION 26 05 46 – UTILITY POLES FOR ELECTRICAL SYSTEMS**

**PART 1: GENERAL**

- A. Overhead electrical distribution and transformers are not allowed on this campus.

**PART 2: PRODUCT (NOT USED)**

**PART 3: EXECUTION (NOT USED)**

**END OF SECTION 26 05 46**